



NEW - LARGE DISPLAY WATER RESISTANT STOPWATCH 810035

Sonically welded case insures excellent water resistance. Large $\frac{5}{8}$ " high display for good visibility. Counts up to 24 hours with resolution of $\frac{1}{100}$ second for the first 40 min. and 1 second resolution thereafter. Has lap function. Also features an alarm clock and a calendar. Button cell battery included.

Dim: $2\frac{7}{8}$ " x $3\frac{1}{4}$ " x $\frac{3}{4}$ ". Weight: 2.4 oz.



With N.I.S.T. traceable certificate of compliance: 810035C



NEW - 100 MEMORY WATER RESISTANT STOPWATCH 810036

Sonically welded case insures excellent water resistance. Previous 100 lap times are stored in memory so there is no need to look away from a test to make notes. Counts up to 10 hours in $\frac{1}{100}$ second resolution. Large display simultaneously shows total elapsed time, split time, current lap time, and lap counter. A unique function is the stopwatch's ability to calculate average strokes, beats, or pulses, per minute based on the timing of 3 sample strokes. Also features a clock and a calendar. Button cell battery included. Dim: $2\frac{7}{8}$ " x $3\frac{1}{4}$ " x $\frac{3}{4}$ ". Weight: 2.8 oz.



With N.I.S.T. traceable certificate of compliance: 810036C