



### LIGHTWEIGHT STOPWATCH 810013

Large control buttons and extreme lightweight, (1.1 oz.), make this stopwatch comfortable to hold and use. Counts to 24 hours in 1/100th second resolution for the first 30 minutes with 1 second resolution thereafter. Split interval function. Also a 12/24 hour alarm clock, calendar, and an hourly chime option.

Dim: 2 7/8" x 2 3/16" x 3/4". Weight: 2.4 oz.



With N.I.S.T. traceable certificate of compliance: 810013C



### 8 MEMORY STOPWATCH 810029

Counts up or down to 10 hours. Ideal for multiple and simultaneous processes. In stopwatch mode current lap time shown in upper display, cumulative total in lower one. Memory stores last 8 lap times so there is no need to look away from a test to make notes. In timer mode upper display shows original setting while lower one counts down. Warning alarm sounds at 30 seconds before time elapses and when time has elapsed. Countdown cycles repeat upon completion. 30 second shuttle timer for use during timeouts. Lap counter shows number of laps, (up to 99), in stopwatch mode and number of cycles repeated in timer mode. Pacesetter function can be set to beep continually from every 0.25 seconds to every 30 seconds. Shock resistant, superb hand grip.

Dim: 2 3/4" x 2 1/4" x 3/4". Weight: 2.7 oz.



With N.I.S.T. traceable certificate of compliance: 810029C



### 60 MEMORY STOPWATCH 810033

Similar functions to 810029 plus; 60 lap memories, fastest, slowest, and average lap times, alarm clock function. Water resistant. Dim: 3" x 2 1/4" x 3/4". Weight: 2.3 oz.



With N.I.S.T. traceable certificate of compliance: 810033C